


**CARTA DE ESTACIONAMENTO
DE AERONAVES (PDC)
AIRCRAFT PARKING/
DOCKING CHART (PDC)**

BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)

RR-BRASIL

ELEV 276'

ARP N02 50 29 W060 41 32



COORDENADAS DOS PONTOS DE ESTACIONAMENTO PARKING SPOT COORDINATES			
PONTO NR SPOT NR	COORDENADAS COORDINATES	ACL	
PÁTIO 1 / APRON 1			
1	N02 50.54 / W060 41.52	275'	
2	N02 50.52 / W060 41.55	276'	
2B	N02 50.52 / W060 41.55	275'	
3	N02 50.51 / W060 41.58	275'	
3A	N02 50.51 / W060 41.56	275'	
3B	N02 50.50 / W060 41.58	275'	
4	N02 50.50 / W060 41.60	275'	
4A	N02 50.49 / W060 41.59	275'	
4B	N02 50.49 / W060 41.60	275'	
5	N02 50.48 / W060 41.63	275'	
6	N02 50.50 / W060 41.67	275'	
6B	N02 50.50 / W060 41.68	275'	
COORDENADAS DO INS INS COORDINATES			
PONTO NR SPOT NR	COORDENADAS COORDINATES		
1	N02 50 29 / W060 41 35		
2	N02 50 31 / W060 41 39		

MODIFICAÇÕES/CHANGES: PÁTIO/APRON.