

**INSTRUMENT APPROACH
CHART (IAC)**

TAUBATÉ / Base de Aviação de Taubaté, MIL (SBTA)

VOR RWY 26



AD ELEV: 1902'

ATIS NIL	APP NIL	TWR TAUBATÉ 119.90 121.50	GNDC TAUBATÉ 121.70
VOR TAU 112.60 MHz	FINAL CRS 271°	FAF: 3190'	VOR MDA / (OCH): 2450' / (570')

APCH Perdida: Subir para **6000'**. Manter RDL **271** do VOR TAU até **3000'**. Após, curvar à DIREITA para interceptar a RDL **051** do VOR TAU até DILUD para espera.

Missed APCH: Climb to **6000'**. Maintain **271** RDL TAU VOR until **3000'**. After, turn RIGHT to intercept **051** RDL TAU VOR to DILUD for holding.

RMK: NIL.



	0.0	1.3	1.5	3.0	4.5	6.0	TO THR 26 (NM)
	0.1	1.4	1.6	3.1	4.6	6.1	TO TAU (DME)

RWY26	1.3	1.5	2.0	NEPER		KT	060	070	080	090
ALT	2450	2558	2771	3190		FPM	430	500	600	640
(HGT)	570	675	878	1307		FAF-MAPT			NA	

STRAIGHT-IN	CAT	H
	MDA / (OCH)	2450' / (570')
VOR	ALS/NO ALS/ RVR ALS (m)	NIL / 800 / NIL
CIRCLING	MDA / (OCH)	NA
	VIS (m)	

CHANGES: NEW CHART.