



## CODING TABLE

This table supplements information contained in the chart to which it is associated. In spite of the fact the classification of waypoints (fly-by / flyover), courses, distances, altitudes, level and speed restrictions are mandatory, the providers may use the information as they find appropriate in order to code procedures. In other words, in case any particular coding is applied, it is mandatory for it to reflect the procedure published in the chart.

Identification	Aerodrome	Chart Code	AIRAC AMDT
SID RNAV PENSO 1A RWY 11	PORTO ALEGRE / Salgado Filho, INTL (SBPA)	SBPA_SID_02O	12 OCT 17

Seq	Transition	Path Terminator	Navaid / Fix / WPT	Type / Function	Flyover (Y/N)	Navaid	Course Mag (True)	Dist (NM)	Turn (L/R)	IAS (KT)	Altitude (FT)	Gradient (%)	Perform.
<b>RWY 11</b>													
010	Runway	CF	NETPI	---	Y	---	108 (091.3)	5.0	---	-230	---	5.5	RNAV 1 or RNP 1
<b>TRNS PENSO</b>													
010	Enroute	IF	NETPI	---	N	---	---	---	---	---	---	---	---
020	Enroute	TF	NUVUK	---	N	---	026 (008.5)	10.2	---	-230	-6000	---	RNAV 1 or RNP 1
030	Enroute	TF	SILID	---	N	---	026(008.5)	4.4	---	---	+5000	---	RNAV 1 or RNP 1
040	Enroute	TF	OBLOS	---	N	---	023(005.9)	47.4	---	---	---	---	RNAV 1 or RNP 1
050	Enroute	TF	ASBOV	---	N	---	023(005.9)	8.2	---	---	---	---	RNAV 1 or RNP 1

060	Enroute	TF	ANROB	---	N	---	023(006.0)	6.5	---	---	-21000		RNAV 1 or RNP 1
070	Enroute	TF	PENSO	---	N	---	024(005.8)	41.0	---	---	---	---	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NETPI	S 29:59:48.00W 51:03:48.60
NUVUK	S 29:49:39.60W 51:02:04.20
SILID	S 29:45:17.40W 51:01:19.20
OBLOS	S 28:58:11.57W 50:55:45.47
ASBOV	S 28:49:59.89W 50:54:48.01
ANROB	S 28:43:33.83W 50:54:02.34
PENSO	S 28:02:46.80W 50:49:19.20

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11	S 29:59:41.46 W 51:09:33.80	11.15 ft MSL

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
=	MANDATORY
	RECOMMENDED
SDF	STEP DOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT